



## OVP Guide to Using Processor Models

### Model specific information for POWER\_m470

Imperas Software Limited  
Imperas Buildings, North Weston  
Thame, Oxfordshire, OX9 2HA, U.K.  
docs@imperas.com



Author	Imperas Software Limited
Version	20211118.0
Filename	OVP_Model_Specific_Information_powerpc32_400_m470.pdf
Created	18 November 2021
Status	OVP Standard Release

## Copyright Notice

Copyright (c) 2021 Imperas Software Limited. All rights reserved. This software and documentation contain information that is the property of Imperas Software Limited. The software and documentation are furnished under a license agreement and may be used or copied only in accordance with the terms of the license agreement. No part of the software and documentation may be reproduced, transmitted, or translated, in any form or by any means, electronic, mechanical, manual, optical, or otherwise, without prior written permission of Imperas Software Limited, or as expressly provided by the license agreement.

## Right to Copy Documentation

The license agreement with Imperas permits licensee to make copies of the documentation for its internal use only. Each copy shall include all copyrights, trademarks, service marks, and proprietary rights notices, if any.

## Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the readers responsibility to determine the applicable regulations and to comply with them.

## Disclaimer

IMPERAS SOFTWARE LIMITED, AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

## Model Release Status

This model is released as part of OVP releases and is included in OVPworld packages. Please visit [OVPworld.org](http://OVPworld.org).

# Contents

<b>1</b>	<b>Overview</b>	<b>1</b>
1.1	Description . . . . .	1
1.2	Licensing . . . . .	1
1.3	Limitations . . . . .	1
1.4	Verification . . . . .	2
1.5	Features . . . . .	2
<b>2</b>	<b>Configuration</b>	<b>3</b>
2.1	Location . . . . .	3
2.2	GDB Path . . . . .	3
2.3	Semi-Host Library . . . . .	3
2.4	Processor Endian-ness . . . . .	3
2.5	QuantumLeap Support . . . . .	3
2.6	Processor ELF code . . . . .	3
<b>3</b>	<b>All Variants in this model</b>	<b>4</b>
<b>4</b>	<b>Bus Master Ports</b>	<b>5</b>
<b>5</b>	<b>Bus Slave Ports</b>	<b>6</b>
<b>6</b>	<b>Net Ports</b>	<b>7</b>
<b>7</b>	<b>FIFO Ports</b>	<b>8</b>
<b>8</b>	<b>Formal Parameters</b>	<b>9</b>
8.1	Parameter values . . . . .	9
<b>9</b>	<b>Execution Modes</b>	<b>11</b>
<b>10</b>	<b>Exceptions</b>	<b>12</b>
<b>11</b>	<b>Hierarchy of the model</b>	<b>13</b>
11.1	Level 1 . . . . .	13
<b>12</b>	<b>Model Commands</b>	<b>14</b>
12.1	Level 1 . . . . .	14
12.1.1	isync . . . . .	14
12.1.2	itrace . . . . .	14

<b>13 Registers</b>	<b>15</b>
13.1 Level 1 . . . . .	15
13.1.1 User . . . . .	15
13.1.2 FloatingPoint . . . . .	16
13.1.3 System . . . . .	16

# Chapter 1

## Overview

This document provides the details of an OVP Fast Processor Model variant.

OVP Fast Processor Models are written in C and provide a C API for use in C based platforms. The models also provide a native interface for use in SystemC TLM2 platforms.

The models are written using the OVP VMI API that provides a Virtual Machine Interface that defines the behavior of the processor. The VMI API makes a clear line between model and simulator allowing very good optimization and world class high speed performance. Most models are provided as a binary shared object and also as source. This allows the download and use of the model binary or the use of the source to explore and modify the model.

The models are run through an extensive QA and regression testing process and most model families are validated using technology provided by the processor IP owners. There is a companion document (OVP Guide to Using Processor Models) which explains the general concepts of OVP Fast Processor Models and their use. It is downloadable from the OVPworld website documentation pages.

### 1.1 Description

PPC32 Family Processor Model. Providing PPC 400 family variants.

### 1.2 Licensing

Open Source Apache 2.0

### 1.3 Limitations

This model is currently under development

The FPU is incomplete

FPU exceptions are not implemented

Some Single Floating Point FPU instructions are not implemented

The MMU is not implemented

## **1.4 Verification**

Basic verification of ISA against golden reference has been performed

## **1.5 Features**

# Chapter 2

## Configuration

### 2.1 Location

This model's VLVN is `power.ovpworld.org/processor/powerpc32_400/1.0`.

The model source is usually at:

`$IMPERAS_HOME/ImperasLib/source/power.ovpworld.org/processor/powerpc32_400/1.0`

The model binary is usually at:

`$IMPERAS_HOME/lib/$IMPERAS_ARCH/ImperasLib/power.ovpworld.org/processor/powerpc32_400/1.0`

### 2.2 GDB Path

The default GDB for this model is: `$IMPERAS_HOME/lib/$IMPERAS_ARCH/gdb/powerpc-elf-gdb`.

### 2.3 Semi-Host Library

The default semi-host library file is `power.ovpworld.org/semihosting/powerpc32Newlib/1.0`

### 2.4 Processor Endian-ness

This model can be set to either endian-ness (normally by a pin, or the ELF code).

### 2.5 QuantumLeap Support

This processor is qualified to run in a QuantumLeap enabled simulator.

### 2.6 Processor ELF code

The ELF code supported by this model is: `0x14`.

## Chapter 3

# All Variants in this model

This model has these variants

<b>Variant</b>	Description
m476	
m470	(described in this document)
m460	
m440	

Table 3.1: All Variants in this model



## Chapter 4

# Bus Master Ports

This model has these bus master ports.

<b>Name</b>	min	max	Connect?	Description
INSTRUCTION	32	32	mandatory	
DATA	32	32	optional	

Table 4.1: Bus Master Ports

## Chapter 5

# Bus Slave Ports

This model has no bus slave ports.

## Chapter 6

# Net Ports

This model has these net ports.

<b>Name</b>	Type	Connect?	Description
reset	input	optional	

Table 6.1: Net Ports

## Chapter 7

# FIFO Ports

This model has no FIFO ports.

# Chapter 8

## Formal Parameters

Name	Type	Description
variant	Enumeration	Selects variant (either a generic UISA or a specific model)
verbose	Boolean	Specify verbose output messages
endian	Endian	Specify Model endian
UISA.I.B	Boolean	UISA Feature UISA.I.B
UISA.I.BCDA	Boolean	UISA Feature UISA.I.BCDA
UISA.I.S	Boolean	UISA Feature UISA.I.S
UISA.I.E	Boolean	UISA Feature UISA.I.E
UISA.I.E.PC	Boolean	UISA Feature UISA.I.E.PC
UISA.I.E.PD	Boolean	UISA Feature UISA.I.E.PD
UISA.I.EC	Boolean	UISA Feature UISA.I.EC
UISA.I.FP	Boolean	UISA Feature UISA.I.FP
UISA.I.DFP	Boolean	UISA Feature UISA.I.DFP
UISA.I.MA	Boolean	UISA Feature UISA.I.MA
UISA.I.SP	Boolean	UISA Feature UISA.I.SP
UISA.I.V	Boolean	UISA Feature UISA.I.V
UISA.I.LMA	Boolean	UISA Feature UISA.I.LMA
UISA.I.WT	Boolean	UISA Feature UISA.I.WT
UISA.I.VLE	Boolean	UISA Feature UISA.I.VLE
ENABLE.FPU	Uns32	Enable FPU At Startup
UNIMP.TO.NOP	Boolean	Map Unimplemented Instructions to NOP
WARN.NOP	Boolean	Warn when executing nop-mapped instructions

Table 8.1: Parameters

### 8.1 Parameter values

These are the current parameter values.

Name	Value
<b>(Others)</b>	
variant	m470
verbose	T
endian	none
UISA.I.B	F
UISA.I.BCDA	F
UISA.I.S	F
UISA.I.E	F

UISA.IE_PC	F
UISA.IE_PD	F
UISA.IEC	F
UISA.IFP	F
UISA.IDFP	F
UISA.IMA	F
UISA.ISP	F
UISA.IV	F
UISA.LLMA	F
UISA.LWT	F
UISA.IVLE	F
ENABLE_FPU	0
UNIMP_TO_NOP	F
WARN_NOP	F

Table 8.2: Parameter values

## Chapter 9

# Execution Modes

This model does not have different execution modes.

## Chapter 10

# Exceptions

<b>Exception</b>	<b>Code</b>
Reset	0
Undefined	1
Arith	2
RdAlign	3
WrAlign	4
RdAbort	5
WrAbort	6
RdPriv	7
WrPriv	8
Fetch	9

Table 10.1: Exceptions implemented by this processor



# Chapter 11

## Hierarchy of the model

A CPU core may be configured to instance many processors of a Symmetrical Multi Processor (SMP). A CPU core may also have sub elements within a processor, for example hardware threading blocks.

OVP processor models can be written to include SMP blocks and to have many levels of hierarchy. Some OVP CPU models may have a fixed hierarchy, and some may be configured by settings in a configuration register. Please see the register definitions of this model.

This model documentation shows the settings and hierarchy of the default settings for this model variant.

### 11.1 Level 1

This level in the model hierarchy has 2 commands.

This level in the model hierarchy has 3 register groups:

<b>Group name</b>	<b>Registers</b>
User	32
FloatingPoint	32
System	7

Table 11.1: Register groups

This level in the model hierarchy has no children.

# Chapter 12

## Model Commands

A Processor model can implement one or more **Model Commands** available to be invoked from the simulator command line, from the OP API or from the Imperas Multiprocessor Debugger.

### 12.1 Level 1

#### 12.1.1 isync

specify instruction address range for synchronous execution

Argument	Type	Description
-addresshi	Uns64	end address of synchronous execution range
-addresslo	Uns64	start address of synchronous execution range

Table 12.1: isync command arguments

#### 12.1.2 itrace

enable or disable instruction tracing

Argument	Type	Description
-after	Uns64	apply after this many instructions
-enable	Boolean	enable instruction tracing
-instructioncount	Boolean	include the instruction number in each trace
-memory	String	show memory accesses by this instruction. Argument can be any combination of X (execute), L (load or store access) and S (system)
-off	Boolean	disable instruction tracing
-on	Boolean	enable instruction tracing
-processorname	Boolean	Include processor name in all trace lines
-registerchange	Boolean	show registers changed by this instruction
-registers	Boolean	show registers after each trace

Table 12.2: itrace command arguments

# Chapter 13

## Registers

### 13.1 Level 1

#### 13.1.1 User

Registers at level:1, group:User

Name	Bits	Initial-Hex	RW	Description
GPR0	32	0	rw	
GPR1	32	0	rw	
GPR2	32	0	rw	
GPR3	32	0	rw	
GPR4	32	0	rw	
GPR5	32	0	rw	
GPR6	32	0	rw	
GPR7	32	0	rw	
GPR8	32	0	rw	
GPR9	32	0	rw	
GPR10	32	0	rw	
GPR11	32	0	rw	
GPR12	32	0	rw	
GPR13	32	0	rw	
GPR14	32	0	rw	
GPR15	32	0	rw	
GPR16	32	0	rw	
GPR17	32	0	rw	
GPR18	32	0	rw	
GPR19	32	0	rw	
GPR20	32	0	rw	
GPR21	32	0	rw	
GPR22	32	0	rw	
GPR23	32	0	rw	
GPR24	32	0	rw	
GPR25	32	0	rw	
GPR26	32	0	rw	
GPR27	32	0	rw	
GPR28	32	0	rw	
GPR29	32	0	rw	
GPR30	32	0	rw	
GPR31	32	0	rw	

Table 13.1: Registers at level 1, group:User

### 13.1.2 FloatingPoint

Registers at level:1, group:FloatingPoint

Name	Bits	Initial-Hex	RW	Description
FPR0	64	0	rw	
FPR1	64	0	rw	
FPR2	64	0	rw	
FPR3	64	0	rw	
FPR4	64	0	rw	
FPR5	64	0	rw	
FPR6	64	0	rw	
FPR7	64	0	rw	
FPR8	64	0	rw	
FPR9	64	0	rw	
FPR10	64	0	rw	
FPR11	64	0	rw	
FPR12	64	0	rw	
FPR13	64	0	rw	
FPR14	64	0	rw	
FPR15	64	0	rw	
FPR16	64	0	rw	
FPR17	64	0	rw	
FPR18	64	0	rw	
FPR19	64	0	rw	
FPR20	64	0	rw	
FPR21	64	0	rw	
FPR22	64	0	rw	
FPR23	64	0	rw	
FPR24	64	0	rw	
FPR25	64	0	rw	
FPR26	64	0	rw	
FPR27	64	0	rw	
FPR28	64	0	rw	
FPR29	64	0	rw	
FPR30	64	0	rw	
FPR31	64	0	rw	

Table 13.2: Registers at level 1, group:FloatingPoint

### 13.1.3 System

Registers at level:1, group:System

Name	Bits	Initial-Hex	RW	Description
PC	32	0	rw	program counter
MSR	32	0	rw	
CR	32	0	rw	
LR	32	0	rw	
CTR	32	0	rw	
XER	32	0	rw	
FPSCR	32	0	rw	

Table 13.3: Registers at level 1, group:System