



## OVP Guide to Using Processor Models

### Model Specific Information for variant ARM\_ARM940T

#### Imperas Software Limited

Imperas Buildings, North Weston  
Thame, Oxfordshire, OX9 2HA, UK  
docs@imperas.com



Author	Imperas Software Limited
Version	0.5
Filename	OVP_Model_Specific_Information_arm_ARM940T.pdf
Created	19 May 2017
Status	OVP Standard Release

## Copyright Notice

All rights reserved. This software and documentation contain information that is the property of Imperas Software Limited. The software and documentation are furnished under a license agreement and may be used or copied only in accordance with the terms of the license agreement. No part of the software and documentation may be reproduced, transmitted, or translated, in any form or by any means, electronic, mechanical, manual, optical, or otherwise, without prior written permission of Imperas Software Limited, or as expressly provided by the license agreement.

## Right to Copy Documentation

The license agreement with Imperas permits licensee to make copies of the documentation for its internal use only. Each copy shall include all copyrights, trademarks, service marks, and proprietary rights notices, if any.

## Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

## Disclaimer

IMPERAS SOFTWARE LIMITED., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

## Model Release Status

This model is available under a RESTRICTED license. This is normally because the model is proprietary to a specific IP vendor and requires their formal written approval to release this model. A Software License Agreement with confidentiality clauses is required. You must have written approval from Imperas to access and use this model.

Table of Contents

1 Overview.....	4
1.1 Description.....	4
1.2 Licensing.....	4
1.3 Limitations.....	4
1.4 Verification.....	5
1.5 Features.....	5
1.5.1 Core Features.....	5
1.5.2 Memory System.....	5
1.6 Integration Support.....	5
1.6.1 Halt Reason Introspection.....	5
1.6.2 System Register Access Monitor.....	5
1.6.3 System Register Implementation.....	5
2 Configuration.....	5
2.1 Location.....	5
2.2 GDB Path.....	5
2.3 Semi-Host Library.....	6
2.4 Processor Endian-ness.....	6
2.5 QuantumLeap Support.....	6
2.6 Processor ELF Code.....	6
3 Other Variants in this Model.....	6
4 Bus Ports.....	8
5 Net Ports.....	8
6 FIFO Ports.....	8
7 Parameters.....	8
8 Execution Modes.....	9
9 Exceptions.....	10
10 Hierarchy of the model.....	11
10.1 Level 1: CPU.....	11
11 Model Commands.....	12
11.1 Level 1: CPU.....	12
12 Registers.....	12
12.1 Level 1: CPU.....	12
12.1.1 Core.....	12
12.1.2 Control.....	12
12.1.3 User.....	13
12.1.4 FIQ.....	13
12.1.5 IRQ.....	13
12.1.6 Supervisor.....	13
12.1.7 Undefined.....	14
12.1.8 Abort.....	14
12.1.9 Coprocessor_32_bit.....	14
12.1.10 Integration_support.....	15

## 1 Overview

This document provides the details of an OVP Fast Processor Model variant. OVP Fast Processor Models are written in C and provide a C API for use in C based platforms. The models also provide a native interface for use in SystemC TLM2 platforms. The models are written using the OVP VMI API that provides a Virtual Machine Interface that defines the behavior of the processor. The VMI API makes a clear line between model and simulator allowing very good optimization and world class high speed performance. Most models are provided as a binary shared object and also as source. This allows the download and use of the model binary or the use of the source to explore and modify the model.

The models are run through an extensive QA and regression testing process and most model families are validated using technology provided by the processor IP owners.

There is a companion document (OVP Guide to Using Processor Models) which explains the general concepts of OVP Fast Processor Models and their use. It is downloadable from the OVPworld website documentation pages.

### 1.1 Description

ARM Processor Model

### 1.2 Licensing

Usage of binary model under license governing simulator usage.

Note that for models of ARM CPUs the license includes the following terms:

Licensee is granted a non-exclusive, worldwide, non-transferable, revocable licence to:

If no source is being provided to the Licensee: use and copy only (no modifications rights are granted) the model for the sole purpose of designing, developing, analyzing, debugging, testing, verifying, validating and optimizing software which: (a) (i) is for ARM based systems; and (ii) does not incorporate the ARM Models or any part thereof; and (b) such ARM Models may not be used to emulate an ARM based system to run application software in a production or live environment.

If source code is being provided to the Licensee: use, copy and modify the model for the sole purpose of designing, developing, analyzing, debugging, testing, verifying, validating and optimizing software which: (a) (i) is for ARM based systems; and (ii) does not incorporate the ARM Models or any part thereof; and (b) such ARM Models may not be used to emulate an ARM based system to run application software in a production or live environment.

In the case of any Licensee who is either or both an academic or educational institution the purposes shall be limited to internal use.

Except to the extent that such activity is permitted by applicable law, Licensee shall not reverse engineer, decompile, or disassemble this model. If this model was provided to Licensee in Europe, Licensee shall not reverse engineer, decompile or disassemble the Model for the purposes of error correction.

The License agreement does not entitle Licensee to manufacture in silicon any product based on this model.

The License agreement does not entitle Licensee to use this model for evaluating the validity of any ARM patent.

Source of model available under separate Imperas Software License Agreement.

### 1.3 Limitations

Instruction pipelines are not modeled in any way. All instructions are assumed to complete immediately. This means that instruction barrier instructions (e.g. ISB, CP15ISB) are treated as NOPs, with the exception of any undefined instruction behavior, which is modeled. The model does not implement speculative fetch behavior. The branch cache is not modeled. Caches and write buffers are not modeled in any way. All loads, fetches and stores complete immediately and in order, and are fully synchronous (as if the memory was of Strongly Ordered or Device-nGnRnE type). Data barrier instructions (e.g. DSB, CP15DSB) are treated as NOPs, with the exception of any undefined instruction behavior, which is modeled. Cache

manipulation instructions are implemented as NOPs, with the exception of any undefined instruction behavior, which is modeled.

Real-world timing effects are not modeled: all instructions are assumed to complete in a single cycle.

### **1.4 Verification**

Models have been extensively tested by Imperas. ARM9 models have been successfully used by customers to simulate Linux and Nucleus on ArmIntegrator virtual platforms.

### **1.5 Features**

#### **1.5.1 Core Features**

Thumb instructions are supported.

#### **1.5.2 Memory System**

PMSA address translation is implemented.

### **1.6 Integration Support**

This model implements a number of non-architectural pseudo-registers and other features to facilitate integration.

#### **1.6.1 Halt Reason Introspection**

An artifact register HaltReason can be read to determine the reason or reasons that a processor is halted. This register is a bitfield, with the following encoding: bit 0 indicates the processor has executed a wait-for-event (WFE) instruction; bit 1 indicates the processor has executed a wait-for-interrupt (WFI) instruction; and bit 2 indicates the processor is held in reset.

#### **1.6.2 System Register Access Monitor**

If parameter enableSystemMonitorBus is True, an artifact 32-bit bus "SystemMonitor" is enabled for each PE. Every system register read or write by that PE is then visible as a read or write on this artifact bus, and can therefore be monitored using callbacks installed in the client environment (use opBusReadMonitorAdd/opBusWriteMonitorAdd or icmAddBusReadCallback/icmAddBusWriteCallback, depending on the client API). The format of the address on the bus is as follows:

bits 31:26 - zero

bit 25 - 1 if AArch64 access, 0 if AArch32 access

bit 24 - 1 if non-secure access, 0 if secure access

bits 23:20 - CRm value

bits 19:16 - CRn value

bits 15:12 - op2 value

bits 11:8 - op1 value

bits 7:4 - op0 value (AArch64) or coprocessor number (AArch32)

bits 3:0 - zero

As an example, to view non-secure writes to writes to CNTFRQ\_EL0 in AArch64 state, install a write monitor on address range 0x020e0330:0x020e0333.

#### **1.6.3 System Register Implementation**

If parameter enableSystemBus is True, an artifact 32-bit bus "System" is enabled for each PE. Slave callbacks installed on this bus can be used to implement modified system register behavior (use opBusSlaveNew or icmMapExternalMemory, depending on the client API). The format of the address on the bus is the same as for the system monitor bus, described above.

## **2 Configuration**

### **2.1 Location**

The model source and object file is found in the VLNV tree at:  
[arm.ovpworld.org/processor/arm/1.0](http://arm.ovpworld.org/processor/arm/1.0)

### **2.2 GDB Path**

The default GDB for this model is found at:

\$IMPERAS\_HOME/lib/\$IMPERAS\_ARCH/gdb/arm-none-eabi-gdb

### 2.3 *Semi-Host Library*

The default semi-host library file is found in the VLNV tree at :  
[arm.ovpworld.org/semihosting/armNewlib/1.0](http://arm.ovpworld.org/semihosting/armNewlib/1.0)

### 2.4 *Processor Endian-ness*

This model can be set to either endian-ness (normally by a pin, or the ELF code).

### 2.5 *QuantumLeap Support*

This processor is qualified to run in a QuantumLeap enabled simulator.

### 2.6 *Processor ELF Code*

The ELF code supported by this model is: 0x28

## 3 Other Variants in this Model

Table 1.

Variant
ARMv4T
ARMv4xM
ARMv4
ARMv4TxM
ARMv5xM
ARMv5
ARMv5TxM
ARMv5T
ARMv5TExP
ARMv5TE
ARMv5TEJ
ARMv6
ARMv6K
ARMv6T2
ARMv6KZ
ARMv7
ARM7TDMI
ARM7EJ-S
ARM720T
ARM920T
ARM922T
ARM926EJ-S
ARM940T
ARM946E
ARM966E
ARM968E-S
ARM1020E
ARM1022E
ARM1026EJ-S
ARM1136J-S

ARM1156T2-S
ARM1176JZ-S
Cortex-R4
Cortex-R4F
Cortex-A5UP
Cortex-A5MPx1
Cortex-A5MPx2
Cortex-A5MPx3
Cortex-A5MPx4
Cortex-A8
Cortex-A9UP
Cortex-A9MPx1
Cortex-A9MPx2
Cortex-A9MPx3
Cortex-A9MPx4
Cortex-A7UP
Cortex-A7MPx1
Cortex-A7MPx2
Cortex-A7MPx3
Cortex-A7MPx4
Cortex-A15UP
Cortex-A15MPx1
Cortex-A15MPx2
Cortex-A15MPx3
Cortex-A15MPx4
Cortex-A17MPx1
Cortex-A17MPx2
Cortex-A17MPx3
Cortex-A17MPx4
AArch32
AArch64
Cortex-A53MPx1
Cortex-A53MPx2
Cortex-A53MPx3
Cortex-A53MPx4
Cortex-A57MPx1
Cortex-A57MPx2
Cortex-A57MPx3
Cortex-A57MPx4
Cortex-A72MPx1
Cortex-A72MPx2
Cortex-A72MPx3

Cortex-A72MPx4
MultiCluster

## 4 Bus Ports

Table 2.

Type	Name	min	dft	max
master (initiator)	INSTRUCTION	32	32	32
master (initiator)	DATA	32	32	32

## 5 Net Ports

Table 3.

Name	Type	Description
reset	input	Processor reset, active high
fiq	input	FIQ interrupt, active high (negation of nFIQ)
irq	input	IRQ interrupt, active high (negation of nIRQ)
sei	input	System error interrupt, active high

## 6 FIFO Ports

No FIFO Ports in this model.

## 7 Parameters

Table 4.

Name	Type	Description
verbose	Boolean	Specify verbosity of output
showHiddenRegs	Boolean	Show hidden registers during register tracing
UAL	Boolean	Disassemble using UAL syntax
enableSystemBus	Boolean	Add 32-bit artifact System bus port, allowing system registers to be externally implemented
enableSystemMonitorBus	Boolean	Add 32-bit artifact SystemMonitor bus port, allowing system register accesses to be externally monitored
compatibility	Enumeration	Specify compatibility mode ISA=0 gdb=1 nopSVC=2
override_debugMask	Uns32	Specifies debug mask, enabling debug output for model components
override_fcsePresent	Boolean	Specifies that FCSE is present (if true)
override_SCTLR_V	Boolean	Override SCTLR.V with the passed value (enables high vectors)



override_SCTLR_CP15BEN_Present	Boolean	Enable ARMv7 SCTLR.CP15BEN bit (CP15 barrier enable)
override_MIDR	Uns32	Override MIDR/MIDR_EL1 register
override_CTR	Uns32	Override CTR/CTR_EL0 register
override_MPUIR	Uns32	Override MPUIR register
override_CLIDR	Uns32	Override CLIDR/CLIDR_EL1 register
override_AIDR	Uns32	Override AIDR/AIDR_EL1 register
override_ERG	Uns32	Specifies exclusive reservation granule
override_STRoffsetPC12	Boolean	Specifies that STR/STR of PC should do so with 12:byte offset from the current instruction (if true), otherwise an 8:byte offset is used
override_mpuV5ExtAP	Boolean	Specifies that ARMv5 MPU extended access permissions implemented (cp15/5/2 and cp15/5/2)
override_ignoreBadCp15	Boolean	Specifies whether invalid coprocessor 15 access should be ignored (if true) or cause Invalid Instruction exceptions (if false)
override_SGIDisable	Boolean	Override whether GIC SGIs may be disabled (if true) or are permanently enabled (if false)
override_condUndefined	Boolean	Force undefined instructions to take Undefined Instruction exception even if they are conditional
override_deviceStrongAligned	Boolean	Force accesses to Device and Strongly Ordered regions to be aligned
override_Control_V	Boolean	Override SCTLR.V with the passed value (deprecated, use override_SCTLR_V)
override_MainId	Uns32	Override MIDR register (deprecated, use override_MIDR)
override_CacheType	Uns32	Override CTR register (deprecated, use override_CTR)
override_MPUType	Uns32	Override MPUIR register (deprecated, use override_MPUIR)

## 8 Execution Modes

Table 5.

Name	Code
User	16
FIQ	17
IRQ	18
Supervisor	19
Abort	23
Undefined	27
System	31

## 9 Exceptions

Table 6.

<b>Name</b>	<b>Code</b>
Reset	0
Undefined	1
SupervisorCall	2
PrefetchAbort	5
DataAbort	6
IRQ	8
FIQ	9

## 10 Hierarchy of the model

A CPU core may allow the user to configure it to instance many processors of a Symmetrical Multi Processor (SMP). A CPU core may also have sub elements within a processor, for example hardware threading blocks.

OVP processor models can be written to include SMP blocks and to have many levels of hierarchy.

Some OVP CPU models may have a fixed hierarchy, and some may be configured by settings in a configuration register. Please see the register definitions of this model.

This model documentation shows the settings and hierarchy of the default settings for this model variant.

### 10.1 Level 1: CPU

This level in the model hierarchy has 3 commands.

This level in the model hierarchy has 10 register groups:

Table 7.

Group name	Registers
Core	16
Control	3
User	7
FIQ	8
IRQ	3
Supervisor	3
Undefined	3
Abort	3
Coprocessor_32_bit	36
Integration_support	3

This level in the model hierarchy has no children.

## 11 Model Commands

### 11.1 Level 1: CPU

Table 8.

Name	Arguments
debugflags	
isync	specify instruction address range for synchronous execution
itrace	enable or disable instruction tracing

## 12 Registers

### 12.1 Level 1: CPU

#### 12.1.1 Core

Table 9.

Name	Bits	Initial value (Hex)		Description
r0	32	0	rw	
r1	32	0	rw	
r2	32	0	rw	
r3	32	0	rw	
r4	32	0	rw	
r5	32	0	rw	
r6	32	0	rw	
r7	32	0	rw	
r8	32	0	rw	
r9	32	0	rw	
r10	32	0	rw	
r11	32	0	rw	frame pointer
r12	32	0	rw	
sp	32	0	rw	stack pointer
lr	32	0	rw	
pc	32	0	rw	program counter

#### 12.1.2 Control

Table 10.

Name	Bits	Initial value (Hex)		Description
fps	32	0	rw	archaic FPSCR view (for gdb)
cpsr	32	d3	rw	

spsr	32	0	rw	
------	----	---	----	--

### 12.1.3 User

Table 11.

Name	Bits	Initial value (Hex)		Description
r8_usr	32	0	rw	
r9_usr	32	0	rw	
r10_usr	32	0	rw	
r11_usr	32	0	rw	
r12_usr	32	0	rw	
sp_usr	32	0	rw	
lr_usr	32	0	rw	

### 12.1.4 FIQ

Table 12.

Name	Bits	Initial value (Hex)		Description
r8_fiq	32	0	rw	
r9_fiq	32	0	rw	
r10_fiq	32	0	rw	
r11_fiq	32	0	rw	
r12_fiq	32	0	rw	
sp_fiq	32	0	rw	
lr_fiq	32	0	rw	
spsr_fiq	32	0	rw	

### 12.1.5 IRQ

Table 13.

Name	Bits	Initial value (Hex)		Description
sp_irq	32	0	rw	
lr_irq	32	0	rw	
spsr_irq	32	0	rw	

### 12.1.6 Supervisor

Table 14.

Name	Bits	Initial value (Hex)		Description
------	------	---------------------	--	-------------

sp_svc	32	0	rw	
lr_svc	32	0	rw	
spsr_svc	32	0	rw	

### 12.1.7 Undefined

Table 15.

Name	Bits	Initial value (Hex)		Description
sp_undef	32	0	rw	
lr_undef	32	0	rw	
spsr_undef	32	0	rw	

### 12.1.8 Abort

Table 16.

Name	Bits	Initial value (Hex)		Description
sp_abt	32	0	rw	
lr_abt	32	0	rw	
spsr_abt	32	0	rw	

### 12.1.9 Coprocessor\_32\_bit

Table 17.

Name	Bits	Initial value (Hex)		Description
CTR	32	f0f10f1	r-	Cache Type
CleanDCacheLineSW	32	-	-w	Data Cache Line Clean by Set/Way
CleanInvalDCacheLineSW	32	-	-w	Data Cache Line Clean and Invalidate by Set/Way
DAPR	32	0	rw	Data Space Access Permissions
DBR	32	0	rw	
DCLR	32	fff0	rw	Data Cache Lockdown
DCR	32	0	rw	Data Control
DMRR0	32	0	rw	Data Memory Region 0
DMRR1	32	0	rw	Data Memory Region 1
DMRR2	32	0	rw	Data Memory Region 2
DMRR3	32	0	rw	Data Memory Region 3
DMRR4	32	0	rw	Data Memory Region 4
DMRR5	32	0	rw	Data Memory Region 5
DMRR6	32	0	rw	Data Memory Region 6

DMRR7	32	0	rw	Data Memory Region 7
DataSynchBarrier	32	-	-w	Data Synchronization Barrier
IAPR	32	0	rw	Instruction Space Access Permissions
ICLR	32	fff0	rw	Instruction Cache Lockdown
ICR	32	0	rw	Instruction Control
IMRR0	32	0	rw	Instruction Memory Region 0
IMRR1	32	0	rw	Instruction Memory Region 1
IMRR2	32	0	rw	Instruction Memory Region 2
IMRR3	32	0	rw	Instruction Memory Region 3
IMRR4	32	0	rw	Instruction Memory Region 4
IMRR5	32	0	rw	Instruction Memory Region 5
IMRR6	32	0	rw	Instruction Memory Region 6
IMRR7	32	0	rw	Instruction Memory Region 7
InvalDCache	32	-	-w	Invalidate Data Cache
InvalDCacheLineSW	32	-	-w	Invalidate Data Cache Line by Set/Way
InvalICache	32	-	-w	Invalidate Instruction Cache
InvalICacheLineSW	32	-	-w	Invalidate Instruction Cache Line by Set/Way
MIDR	32	41029400	r-	Main ID
PrefetchICacheLine	32	-	-w	Prefetch Instruction Cache Line
SCTLR	32	78	rw	System Control
WaitForInterrupt	32	-	-w	Wait For Interrupt
WaitForInterrupt2	32	-	-w	Wait For Interrupt

### 12.1.10 Integration\_support

Table 18.

Name	Bits	Initial value (Hex)		Description
transactPL	32	1	r-	privilege level of current memory transaction
transactAT	32	0	r-	current memory transaction type: PA=1, VA=0
HaltReason	8	0	r-	bit field indicating halt reason

#