



OVP Guide to Using Processor Models

Model Specific Information for variant renesas_v850_V850ES

Imperas Software Limited

Imperas Buildings, North Weston
Thame, Oxfordshire, OX9 2HA, UK
docs@imperas.com



Author	Imperas Software Limited
Version	0.5
Filename	OVP_Model_Specific_Information_v850_V850ES.pdf
Created	27 February 2018
Status	OVP Standard Release

Copyright Notice

All rights reserved. This software and documentation contain information that is the property of Imperas Software Limited. The software and documentation are furnished under a license agreement and may be used or copied only in accordance with the terms of the license agreement. No part of the software and documentation may be reproduced, transmitted, or translated, in any form or by any means, electronic, mechanical, manual, optical, or otherwise, without prior written permission of Imperas Software Limited, or as expressly provided by the license agreement.

Right to Copy Documentation

The license agreement with Imperas permits licensee to make copies of the documentation for its internal use only. Each copy shall include all copyrights, trademarks, service marks, and proprietary rights notices, if any.

Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

Disclaimer

IMPERAS SOFTWARE LIMITED., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Model Release Status

This model is released as part of OVP releases and is included in OVPworld packages. Please visit OVPworld.org.

Table of Contents

1 Overview.....	4
1.1 Description.....	4
1.2 Licensing.....	4
1.3 Limitations.....	4
1.4 Verification.....	4
1.5 Features.....	4
2 Configuration.....	4
2.1 Location.....	4
2.2 GDB Path.....	4
2.3 Semi-Host Library.....	4
2.4 Processor Endian-ness.....	5
2.5 QuantumLeap Support.....	5
2.6 Processor ELF Code.....	5
3 Other Variants in this Model.....	5
4 Bus Ports.....	5
5 Net Ports.....	5
6 FIFO Ports.....	6
7 Parameters.....	6
8 Execution Modes.....	6
9 Exceptions.....	6
10 Hierarchy of the model.....	7
10.1 Level 1:.....	7
11 Model Commands.....	8
11.1 Level 1:.....	8
11.1.1 isync.....	8
11.1.2 itrace.....	8
12 Registers.....	8
12.1 Level 1:.....	8
12.1.1 User.....	8
12.1.2 System.....	9
12.1.3 Integration_support.....	10

1 Overview

This document provides the details of an OVP Fast Processor Model variant.

OVP Fast Processor Models are written in C and provide a C API for use in C based platforms. The models also provide a native interface for use in SystemC TLM2 platforms. The models are written using the OVP VMI API that provides a Virtual Machine Interface that defines the behavior of the processor. The VMI API makes a clear line between model and simulator allowing very good optimization and world class high speed performance.

Most models are provided as a binary shared object and also as source. This allows the download and use of the model binary or the use of the source to explore and modify the model.

The models are run through an extensive QA and regression testing process and most model families are validated using technology provided by the processor IP owners.

There is a companion document (OVP Guide to Using Processor Models) which explains the general concepts of OVP Fast Processor Models and their use. It is downloadable from the OVPworld website documentation pages.

1.1 Description

V850 Family Processor Model.

1.2 Licensing

Open Source Apache 2.0

1.3 Limitations

The following Debug Registers are non-functional DIR, DBPC, DBPSW

1.4 Verification

Models have been extensively tested by Imperas, In addition Verification suites have been supplied by Renesas for Feature Set validation

1.5 Features

All v850es Instructions are supported.

2 Configuration

2.1 Location

The model source and object file is found in the VLNV tree at:
renesas.ovpworld.org/processor/v850/1.0

2.2 GDB Path

The default GDB for this model is found at:
\$IMPERAS_HOME/lib/\$IMPERAS_ARCH/gdb/v850-elf-gdb

2.3 Semi-Host Library

The default semi-host library file is found in the VLNV tree at :
renesas.ovpworld.org/semihosting/v850Newlib/1.0

2.4 Processor Endian-ness

This is a LITTLE endian model.

2.5 QuantumLeap Support

This processor is qualified to run in a QuantumLeap enabled simulator.

2.6 Processor ELF Code

ELF codes supported by this model are: 0x57, 0x24, 0x70f1, 0x70ff and 0x747b.

3 Other Variants in this Model

Table 1. All variants in this model

Variant
V850
V850E1
V850E1F
V850ES
V850E2
V850E2M
V850E2R

4 Bus Ports

Table 2. Bus Ports

Type	Name	min	max
master (initiator)	INSTRUCTION	28	32
master (initiator)	DATA	28	32

5 Net Ports

Table 3. Net Ports

Name	Type	Description
intp	input	Interrupt Port
nmi0	input	Non-Maskable Interrupt Port
nmi1	input	Non-Maskable Interrupt Port
nmi2	input	Non-Maskable Interrupt Port
reset	input	Reset Port
mireti	output	Return from Interrupt Port

intack	output	Interrupt Acknowledge Port
--------	--------	----------------------------

6 FIFO Ports

No FIFO Ports in this model.

7 Parameters

Table 4. Parameters that can be set in the model, type:

Name	Type	Description
verbose	Boolean	Specify verbose output messages
GDBSIMMODE	Boolean	GDB Simulator Compatibility Mode
nofpu	Boolean	Disable Processor Internal FPU
RBASE	Uns32	RBASE register Reset vector Address
ucbank	Boolean	Enable the User Compatible Bank Registers (eg, VFOREST)
PEID	Uns32	Processor element number
SPID	Uns32	System Protection Number

8 Execution Modes

No execution modes.

9 Exceptions

Table 5. Exceptions handled by the model, type:

Name	Code	Description
reset	0	Reset Signal Exception
nmi0	16	Non Maskable Interrupt(0) Exception
nmi1	32	Non Maskable Interrupt(1) Exception
nmi2	48	Non Maskable Interrupt(2) Exception
intp	128	Maskable Interrupt Exception - Vector value = (0x0000ffff AND intp)
fetrap	48	FETRAP Exception
trap0	64	TRAP0 Exception
trap1	80	TRAP1 Exception
ilgop	96	Illegal OP CODE Exception
rie	48	Reserved Instruction Exception

10 Hierarchy of the model

A CPU core may allow the user to configure it to instance many processors of a Symmetrical Multi Processor (SMP). A CPU core may also have sub elements within a processor, for example hardware threading blocks.

OVP processor models can be written to include SMP blocks and to have many levels of hierarchy.

Some OVP CPU models may have a fixed hierarchy, and some may be configured by settings in a configuration register. Please see the register definitions of this model.

This model documentation shows the settings and hierarchy of the default settings for this model variant.

10.1 Level 1:

This level in the model hierarchy has 2 commands.

This level in the model hierarchy has 3 register groups:

Table 6. Register groups

Group name	Registers
User	32
System	14
Integration_support	8

This level in the model hierarchy has no children.

11 Model Commands

11.1 Level 1:

11.1.1 *isync*

specify instruction address range for synchronous execution

Table 7. *isync* command arguments

Argument	Type	Description
-addresshi	Uns64	end address of synchronous execution range
-addresslo	Uns64	start address of synchronous execution range

11.1.2 *itrace*

enable or disable instruction tracing

Table 8. *itrace* command arguments

Argument	Type	Description
-after	Uns64	apply after this many instructions
-enable	Boolean	enable instruction tracing
-instructioncount	Boolean	include the instruction number in each trace
-off	Boolean	disable instruction tracing
-on	Boolean	enable instruction tracing
-registerchange	Boolean	show registers changed by this instruction
-registers	Boolean	show registers after each trace

12 Registers

12.1 Level 1:

12.1.1 *User*

Table 9. Registers at level 1, type: , register group: 'User'

Name	Bits	Initial value (Hex)		Description
R0	32	0	r-	Zero Register
R1	32	0	rw	Assembler-reserved register
R2	32	0	rw	Address/data variable register (when the real-time OS to be used is not using r2)
R3	32	0	rw	Stack pointer (SP)
R4	32	0	rw	Global pointer (GP)
R5	32	0	rw	Test pointer (TP)
R6	32	0	rw	Address/data variable registers
R7	32	0	rw	Address/data variable registers
R8	32	0	rw	Address/data variable registers
R9	32	0	rw	Address/data variable registers

R10	32	0	rw	Address/data variable registers
R11	32	0	rw	Address/data variable registers
R12	32	0	rw	Address/data variable registers
R13	32	0	rw	Address/data variable registers
R14	32	0	rw	Address/data variable registers
R15	32	0	rw	Address/data variable registers
R16	32	0	rw	Address/data variable registers
R17	32	0	rw	Address/data variable registers
R18	32	0	rw	Address/data variable registers
R19	32	0	rw	Address/data variable registers
R20	32	0	rw	Address/data variable registers
R21	32	0	rw	Address/data variable registers
R22	32	0	rw	Address/data variable registers
R23	32	0	rw	Address/data variable registers
R24	32	0	rw	Address/data variable registers
R25	32	0	rw	Address/data variable registers
R26	32	0	rw	Address/data variable registers
R27	32	0	rw	Address/data variable registers
R28	32	0	rw	Address/data variable registers
R29	32	0	rw	Address/data variable registers
R30	32	0	rw	Element pointer (EP)
R31	32	0	rw	Link pointer (LP)

12.1.2 System

Table 10. Registers at level 1, type: , register group: 'System'

Name	Bits	Initial value (Hex)		Description
EIPC	32	0	rw	Interrupt status-saving register PC
EIPSW	32	0	rw	Interrupt status-saving register PSW
FEPC	32	0	rw	NMI status-saving register PC
FEPSW	32	0	rw	NMI status-saving register PSW
ECR	32	0	rw	Exception cause register
PSW	32	20	rw	Program status word
CTPC	32	0	rw	CALLT status-saving register PC
CTPSW	32	0	rw	CALLT status-saving register PSW
DBPC	32	0	rw	Exception/Debug trap status-saving register PC
DBPSW	32	0	rw	Exception/Debug trap status-saving register PSW
CTBP	32	0	rw	CALLT base pointer
DIR	32	0	rw	Debug Interface register
PC	32	0	rw	Program Counter
FP	32	0	r-	

12.1.3 Integration_support

Table 11. Registers at level 1, type: , register group: 'Integration_support'

Name	Bits	Initial value (Hex)		Description
stop	32	0	rw	Support Register for Stopping Processor
ResultHi	32	0	rw	External ResultHi Register
ResultLo	32	0	rw	External ResultLo Register
ResultSz	8	0	rw	External ResultSz Register
ResultId	8	0	rw	External ResultId Register
ResultFlg	32	0	rw	External ResultFlg Register
ResultCC	32	0	rw	External ResultCC Register
FLG_LL	8	0	rw	Load/Store Exclusive FLG_LL

#